

muRata

Library for Keysight ADS (for 2011 and later)

User Manual

1

0. Contents



- 1. About this manual
- 2. Operation environment
- **3.** How to install
- 4. How to use
- 5. Contact



- This manual is for users of the design kit (the "library") that provides the parameters of Murata Manufacturing Co., Ltd. ("Murata"). It describes the operations from library installation to using the library in the schematic window.
 - Although operating the Library in accordance with this manual can basically perform the required operations, some operations may differ partially depending on the environment used.

2. Operation environment



- This manual is described based on the following environment. See the manuals for the PC, etc. used in the actual environment.
 - OS: Windows 7
 - It is necessary to have the administrative right to install the library.
 - ADS: ADS2011.05 2016.01
 - Unavailable with ADS2009U1 or previous versions

3. How to install (1)




The procedures for both installing in a newly created workspace and an existing workspace are described below. In both cases, the basic flow is:

- 1) Unzip the downloaded ZIP format library.
- 2) Place the folder created after unzipping in your desired folder.
- 3) Specify the "lib.defs" file in the library.

When starting installation from "Unzip Design Kit..." described below, 3) can be omitted.

[Procedures for Installing in a Newly Created Workspace]

- 1. The procedure for installing before creating the workspace and after creating the workspace are described below.
- 1-1. Procedure for installing before creating the workspace
 - 1-1-(1). Select "DesignKits" -> "Unzip Design Kit..." in the main window.



3. How to install (2)



- 1-1-(2). Select the folder containing the downloaded library, and then select the library.
- 1-1-(3). Select your desired folder for the unzipped library (example: C:¥Agilent¥ADS2011_05¥custom) and click "Choose".

Belect directory to unzip file	1-1-(3). Select your desired folder and click
Look in: 🔐 C#Agilent#ADS2011_06#custom 🔸 🔾 🔾 🕼 🔃 [Choose".
Administrator	
Directory:	
Files of type: Directories	


1-1-(4). Check that the "Murata_static" folder has been created in the unzipped folder.

This completes the installation.

3. How to install (3)



- 1-2. Procedure for installing after creating the workspace
- 1-2-(1). Select "DesignKits" -> "Unzip Design Kit..." in the main window.




1-2-(2). Select the folder containing the downloaded library, and then select the library.

3. How to install (4)




1-2-(3). Select your desired folder for the unzipped library (example: C:¥Agilent¥ADS2011_05¥custom) and click "Choose".



1-2-(3). Select your desired folder and click "Choose".

1-2-(4). The "Add Design Kit" window appears. Click "Yes" in the window.



1-2-(5). Check that the "Murata_static" folder has been created in the unzipped folder.

This completes the installation.

3. How to install (5)



<Supplementary information: Confirmation of installation completion>


- (1) If you install before creating the workspace at 1-1., create a new workspace. (Perform the same procedure if the existing workspace is opened.)
- (2) Select "DesignKits" -> "Manage Favorite Design Kits..." in the main window. The "Manage Favorite Design Kits" window appears and the "In Current Workspace" item in the "muRataLibWeb" line is checked.

Advanced Des	sign System	2011.05 (Main)	Statement of the local division in which the local division in the local division in the local division in the	
File View For		Library View Ma	its DesignGuide Help zip Design Kit nage Favorite Design Kits	(2) When the "Manage Favorite Design Kits" window is displayed, this checkbox is selected
Manage Favorite	-	In Courset Western	Librari Definition Sila	
Name muRataLibWeb	Version 4.0	In Current Workspace	Library Definition File \$HPEESOF_DIR¥custom¥muRataLibWe	b_j¥lib.defs
Add Zipped Design H		v Definition File) Remove fr 11_05¥test0_05_wrk [«] .	om List Close	Help

3. How to install (6)



(3) Select "DesignKits" -> "Manage Libraries..." in the main window. The "Manage Libraries" window appears and the library path is added.



3. How to install (7)




[Procedures for Installing in an Existing Workspace]

2. First, open an existing workspace. Two installation procedures are described below.

2-1. Pattern 1

- 2-1-(1). Unzip the downloaded library (murata_lib_ads2011later_*e.zip) and place the created folder "Murata_static" into your desired folder (example: C:¥Agilent¥ADS2011_05¥custom).
- 2-1-(2). Select "DesignKits" -> "Manage Libraries..." in the main window. The "Manage Libraries" window appears. Click "Add Library Definition File".




3. How to install (8)



2-1-(3). Select the "lib.defs" file in the "Murata_static" folder and click "Open".

2-1-(4). The library path is added to the "Manage Libraries" window.



This completes the installation.

3. How to install (9)



2-2. Pattern 2


- 2-2-(1). Unzip the downloaded library (murata_lib_ads2011later_*e.zip) and place the created folder "Murata_static" into your desired folder (example: C:¥Agilent¥ADS2011_05¥custom).
- 2-2-(2). Select "DesignKits" -> "Manage Libraries..." in the main window. The "Manage Libraries" window appears. Click "Add Library Definition File".

Advanced Design System 2011.		
File View Options Tools Wi	View Manage Libraries	2-2-(2). Select "Manage Libraries" and click "Add Design Kit from Favorites".
Manage Libraries		
Libraries and library definition files used by this wo	rkspace.	
Name Path	Mode	
Add Library Definition File	¥oalibs¥dsp.defs Shared	

3. How to install (10)




2-2-(3). If there is a library you want to install in the displayed window, select the checkbox (if not, go to 2-2-(4)). Click "Yes" on the confirmation window.



3. How to install (11)






This completes the installation.

3. How to install (12)



2-2-(4). If you cannot find the library you want to install on the window of 2-2-(3) above, click "Add User Favorite Library/PDK..." on the same window.



3. How to install (13)



2-2-(5). Select the "lib.defs" file in the "Murata_static" folder. And click "Yes" on the confirmation window.

Add Design Kit/Library Definitions I	File to Open Workspace	2-	2-(5). When "lib.defs" is selected,
Are you sure you want to add "muRataLibWeb" to the current workspace?			the confirmation window appears. Click "Yes".
	Yes <u>N</u> o		
Add Library To Workspace	es, & library definition files into the workspace.		
	s, a library definition mes into the workspace.		
 ADS Libraries Analog/RF DSP Site Libraries DemoKit DemoKit_Non_Linear User Favorite Libraries and PDKs W muRataLibWeb Add User Favorite Library/PDK 	\$HPEESOF_DIR¥custom¥muRataLibWeb_···		
	Close		

This completes the installation.

1-(1). The Murata product palette list Select View Insert Options Tools Layout Simulate Window DynamicLink DesignGuide Help is displayed as default.


4. How to use (1)

This section describes how to place the components required for using the Murata library, including "NETLIST INCLUDE", on the schematic window, and how to select products within the components.

1. How to place the Components

cell_2 [test0_05_lib:cell_2:schematic] * (Schematic):5

1-(1). In the schematic window shown immediately after startup, the Murata product palette is displayed in the palette list on the left side.






18





1-(2). Change the palette list from "muRata Components" to "muRataLibWeb Set Up". After selecting the displayed palette, move the cursor onto the schematic window and click again to place the "NETLIST INCLUDE" component.




1-(2). Change the palette list and place the "NETLIST INCLUDE" component.





1-(3). Return the palette list from "muRataLibWeb Set Up" to "muRata Components". Using the same procedure as 1-(2), click your desired palette, and then move the cursor onto the schematic window and click again to place the component (the operation mode continues even after placed, but it can be released by pressing the ESC key).



4. How to use (4)



2. How to select products

2-(1). Double-click a component to display the setting window. You can select products from the part number list of "Parameter Entry Mode" on the upper right corner.


muRataLibWeb:GRM02	Parameter Entry Mode		• •	."Pa	rame	ter Ent	ry ivio	ode".	•
Instance Name (name[<start:stop>])</start:stop>	NULL								
01	NULL		10[-[] . / 5	Did ten d	0.005401-1	0.5[011-3.0			
Select Parameter	0:GRM0222C1C100JD05, Ultra-small type, 1:GRM0222C1C120JD05, Ultra-small type, C	H(-55to125[deg])	. 12[pF]. +/-5	[XG], 16[V], 1	100[MHz]-	·8.5[GHz]:1			
PartNumber=NULL ^	2:GRM0222C1C150JD05, Ultra-small type, C 3:GRM0222C1C180, ID05, Ultra-small type, C	H(-55to125[deg]) H(-55to125[deg])	. 15[pF], +/-5 18[pF] +/-5	[%] 16[√].∶ %1 16[√] :	100[MHz]- 100[MHz]-	·8.5[GHz]:2 ·8.5[GHz]:3			
Type="for General Use"	3:GRM0222C1C180JD05, Ultra-small type, C 4:GRM0222C1C220JD05, Ultra-small type, C	H(-55to125[deg])	22[pF] +/-5	x, 16[V]	100[MHz]-	8.5[GHz]:4			
(Size="0402[mm]") ≡	6:GRM0222C1C330JD05, Ultra-small type, C	H(-55to125[deg])	33[pF] +/-5	%], 16[V], 1	100[MHz]-	8.5[GHz]:6			
TempCharacteristics="B(-25to85[dec	7.GRM0222C1C390JD05, Ultra-small type, C 8.GRM0222C1C470JD05, Ultra-small type, C	H(-55to125[deg]) H(-55to125[deg])	. 39[pF], +/-5 47[nF] +/-5	[%] 16[√] ` %1 16[√] `	100[MHz]- 100[MHz]-	·8.5[GHz]:7 ·8.5[GHz]:8			
Value="470000[pF]"	9:GRM0222C0J560JD05, Ultra-small type, Cl 10:GRM0222C1A560JD05, Ultra-small type, C	H(-55to125[deg]),	56[pF], +/-5	%],6.3[V],	100[MHz]-	-8.5[GHz]:9	10		
Tolerance="+/-20[%]"	11:GRM0222C0J680JD05, Ultra-small type, C	CH(-55to125[deg]), 68[pF], +/-	5[%], 6.3[V],	100[MHz]-8.5[GHz]:	11		
(Dimensions="0.4x0.2[mm]")			· ·			• •		•	•
(Dimensions= 0.4X0.2[mm])									
RatedVoltage="50[V]"									
	Display parameter on schematic								•
RatedVoltage="50[V]"	Display parameter on schematic Component Options		· ·		•	· ·	•	•	•
RatedVoltage="50[V]"			· ·	· ·		· ·	•	•	•

4. How to use (5)



3. How to use Discrete Optimize function


3-(1). Double-click a component to display the settings window. Select "Discrete Optimize setting" at the bottom of the part number list of "Parameter Entry Mode" on the upper right corner.



4. How to use (6)



3-(2). The "Nominal Value", "Minimum Value" and "Maximum Value" items are displayed. By specifying each of these items, you can use the Discrete Optimize function.







- For inquiries concerning this library, please go to the following inquiry form on our website.
 - <u>https://www.murata.com/contactform</u>



muRata

Library for Keysight ADS

Tolerance Model

User Manual appendix 01 Oct 2018

0.Contents



- 1. About this manual
- 2. Operation environment
- 3. How to use






- This manual is supplemental explanation about "Tolerance model" added to the "Library for Keysight ADS".
- Tolerance model reflects the upper and lower tolerance in capacitance MLCC. It is used in Monte Carlo simulation etc.
 - Although operating the Library in accordance with this manual can basically perform the required operations, some operations may differ partially depending on the environment used.





• When you installed "Library for Keysight ADS", Tolerance model is available at the same time.






• In the schematic window, palette of Tolerance model(muRata_Components_T) is included.

3. How to use(2)





- Tolerance model components can be placed the schematic as well as traditional MLCC model.
- To identify, the names or icons have "T".

3. How to use(3)




🔛 Edit Instance Parameters	
Library name: muRataLibWeb Cell name: GRM18_T View name: symbol Instance name: C1	
Select Parameter	
PartNumber=GRM1885C1E821JA01 (Type="General Purpose") (Size="1608[mm]/0603[inch]") (TempCharacteristics="C0G(-55to125[deg (RatedVoltage="25[V]")	► Tolerance "+/-5[%]" None Equation Editor Tune/Opt/Stat/DOE Setup
(volue="020[pr]") (Tolerance="+/-5[%]")	
(FreqRange="100[MHz]-8.5[GHz]") LandWidth=0.7 mm LandLength=0.65 mm LandSpace=0.7 mm Add Cut Paste Tolerance:Tolerance	 Display parameter on schematic Component Options
OK Apply	Cancel Help

- The setting window is similar to the traditional one.
- Capacitance changes randomly within the Tolerance shown here.

3. How to use(4)





- This is an example of the MonteCarlo simulation.
- As the line in the graph has a width, the variation caused by tolerance is recognized.